
■ Product Introduction

GVM Twill Pocket Light is a professional video light with a slim metal body that is light and simple. This series have two model: GVM-5S and RGB-7S. GVM-5S equipped with 96 high color rendering CRI95+ beads to help you restore true color, and you can adjust the color temperature from 3200K to 5600K. RGB-7S equipped with 80 high color rendering CRI 95+ beads to help you restore true color, among them, there are 40 RGB beads can realize RGB color control and 40 LED beads support to change the color temperature from 2000K to 5600K. A variety of convenient power supply modes: power can be supplied by the charger during indoor shooting; or built-in lithium battery when shooting outdoors, easy to carry and easy to carry. Use stepless adjustment to control the brightness/color temperature for great convenience.

■ Main Features

- Ultra Heat Dissipation
- Delicate Design with Aviation Aluminum Alloy Housing
- High Color Rendering Index, CRI95+
- Brightness Adjustment
- Color Temperature Adjustment
- RGB Color Control (Only RGB-7S have this function)
- Dual Power System
- Convenient Light Set-Up and Stabilization system

■ Function introduction



- reset button
- 2 battery power indicator Charging socket
- bracket mounting hole **6** color temperature
- adjustment knob 6 brightness adjustment
- **GVM-5S**: power switch RGB-7S: power switch and color mode switch
- soft diffusion adsorption magnet

& LED beads



diffuser.

■ Accessories

■ Using The Light

light before use.

GVM

Velvet bag

Hot shoe

mount

Align the magnet of the soft diffuser

with the magnet on the light, and the

diffuser will automatically attach to

the light, making it easy to install the

Align the screw of the hot shoe mount

with the bracket mounting hole of the

light, and then turn the knob on the

hot shoe mount to the right to fix the

light on the hot shoe mount.

Charger




1 Connect the charger to fully charge the 2 The hot shoe mount can be attached to the camera by snapping the shoe mount into the

camera's boot and turning the

Gift box

Soft diffusion



6 Rotate counterclockwise to loosen the angle fixing knob of the hot shoe mount, adjust to the appropriate angle, and then tighten the angle fixing knob clockwise to fix the angle of the light.




2

6 Above the light is the reset button and the battery power indicator.



GVM-5S


On the left side of the light are the power switch and the light control knob. Press the power swich to rotate the brightness / color temperature knob to quickly control the brightness and color temperature.



Brightness increase

RGB-7S

On the left side of the light are the power switch and the light control knob. Long press and hold the power switc to turn the light on. Rotate the brightness / color temperature knob to quickly control the brightness and color temperature. Press the power switch to change color.



Brightness increase



Model	LED Bead	CRI	LED angle	Voltage	Color Temperature	Power Consumption	Size
GVM-5S	96	95+	45°	DC9V	2000K~5600K	5W	122×80×35mm
RGB-7S	80	95+	120°	DC9V	3200K~5600K	7W	122×80×35mm

Attention

- 1. Do not look at the working light directly.
- 2. Do not cover the working light, ot it will avoid the product cooling to damage it.
- 3. Do not place the Light at flammable items such as alcohol, gasoline or near volatile solvent.
- 4. Do not place any liquid on the Light interior or fall into the Light.
- 5. Power off when you finish using the Light in case of a fire.
- 6. Carefully to move the Light in the case of dropping it down.

■ APP Intelligent Control System

GVM

The light equipped with mobile APP control function, can be controlled by your smart mobile device (above of Android 4.0 or IOS 9.0), to searched and download the GVM Easily APP in major APP stores (such as Apple syore / Google Play. etc.).


Open the light.

Olick on the installed APP.



Register your account and password

Select the light or equipment you purchased.




4

Great Video Maker

For IOS






Click on the menu at the top right.




Click to switch WIFI.




6 Click the Settings button.




To find and click the WIFI (GVM_ LED), feed in the initial password (gvm_admin) to connect the WIFI.



WIFI's' name and password can be modified. (Note: only one GVM-LED signal can be displayed without modifying the name)





Returning to the operator menu, the lights can be controlled (adjust color temperature / brightness / open or close lights, etc.).



By changing the name one by one,

you can decompose different WIFI





GVM-5S/RGB-7S

Product Manual

Add: 338 N Canal St, #20, South San Francisco, CA94080, USA Web: www.gvmled.com Email: support@gvmled.com

download the APP

5