

# 封底的另一面留白，书本形式


## 封底 封面 封面内页

120.00 mm


160.00 mm

# GVM


GREAT VIDEO MAKER



GVM Official website




Facebook



Download APP

Web: [www.gvmltd.com](http://www.gvmltd.com)  
B&H Email: [bh@gvmltd.com](mailto:bh@gvmltd.com)  
GVM Email: [support@gvmltd.com](mailto:support@gvmltd.com)  
Amazon Email: [amazonsupport@gvmltd.com](mailto:amazonsupport@gvmltd.com)  
Warehouse Add: 4301 N Delaware ave, unit D, PHILADELPHIA, PA 19137, USA



**GVM**  
GREAT VIDEO MAKER  
**TQ-S**

## CONTENTS

Product introduction	Page 1
Disclaimers	Page 2
Product details	Page 2
Product structure analysis	Page 3
Installation method	Page 4-7
Function introduction and instruction for use	Page 8
APP playback settings	Page 9-10
Remote control APP	Page 10
Precautions	Page 11
Use and preservation	Page 11
Packing list	Page 12

### PRODUCT INTRODUCTION

Welcome to use "TQ-S". This product is specially created for senior photography enthusiasts. The product can solve the problem of forgetting words and wrong words in live broadcast/studio photography/YouTube video shooting, making broadcasting more relaxed and natural.

The main features of the product are:

- The base and bracket made of aluminum alloy make the equipment both light and strong.
- The whole set of equipment adopts a simple and user-friendly hand-twisted screw structure, which is quick to install and has a multi-position installation method. The distance between the camera/tablet clip/mobile phone clip and the mirror screen and the camera height can be adjusted as needed. The operation is simple and the control is convenient.
- Compatible with the installation of various photographic equipment such as SLR/digital.
- The mirror plane adopts a colorless beamsplitter, a multi-layer dielectric coating (hard film) on the surface, no light loss, suitable for the various high-definition lens, wide-angle design, prompter document display is clear, no reflection, and no flaws will be exposed during shooting.

We firmly believe that the correct use of this product will be of great help to your shooting work. It is strongly recommended that you carefully read the following user guide before using the product.


### DISCLAIMERS

- Before using this product, please read the instructions carefully and make sure use the product correctly. If you don't obey the instructions and warnings, you maybe cause harm to yourself and the people around, or even damage the product and other things around.
- Once you use this product, you are deemed to have read the disclaimer and warning carefully, understand and acknowledge all the terms and contents of this statement, and promise to take full responsibility for the use of this product and possible consequences.


### PRODUCT DETAILS

- Brand : GVM
- Product Name : Teleprompter
- Product model : TQ-S
- Product Type : Photography accessories
- Product Weight : 0.75KG
- Product load : 2KG
- Product Size(mm) : 217×187×112
- Product material : Plastic
- Function / Feature :
  - Compatible with mobile phones and tablets. (within 10.5 inches)
  - Lightweight and easy to assemble and simple to operate
  - A variety of photography equipment including mirrorless cameras, SLR cameras, and camcorders can be used.
- Commodity origin : China, Huizhou


### PRODUCT STRUCTURE ANALYSIS




Clip for Tablet & Phone




Dust cover




Bluetooth remote control




Thumb screw 1/4 Screw




Adapter ring (52/55/58/62/67/72/77/82mm)




Foam ring



Phone clip support




Teleprompter




Foam ring


**Before assembly**




Adapter ring/foam ring




1/4 screw




1/4 screw holes




Phone/tablet clip




Mirror screen



Phone clip support



Phone/tablet clip



1/4 screw holes

**After assembly**

### INSTALLATION METHOD

- As shown in the figure below, install the 'mobile phone/tablet clip' on the teleprompter and tighten the screws.
- As shown in the figure below, install the 'phone/tablet' on the teleprompter.

### Option 1

Vertical recording with mobile phone, the installation method is as follows.

- Move the "big foam ring" from right to left, install to the back of the teleprompter, As shown in the figure.
- The "foam ring" is installed as shown in the figure.
- Install the "mobile phone/tablet clip" on the "Phone clip support" as shown in the figure.

### Option 2

Horizontal recording with mobile phone, the installation method is as shown in the figure below.

- Move the "big foam ring" from right to left, install to the back of the teleprompter, As shown in the figure.
- The "foam ring" is installed as shown in the figure.
- Install the "mobile phone/tablet clip" on the "Phone clip support" as shown in the figure.

### Option 3

SLR Camera/Micro SLR recording, the installation method is as shown in the figure below.

- Choose the adapter ring according to the camera you are using.
- Install the "adapter ring" to the camera.
- When the installation is complete, as shown in the figure.
- Move the "adapter ring" from right to left, install to the back of the teleprompter, As shown in the figure.

### Option 4

There are three screw holes at the bottom of the teleprompter, which can be installed on a tripod.

- There are three screw holes at the bottom of the teleprompter, which can be installed on a tripod.

### FUNCTION INSTRUCTION & INSTRUCTION FOR USE

- The content displayed by the reflective tablet/mobile phone :

The mirror screen can reflect the content displayed on the tablet/mobile phone below when the camera is shooting, Make the person being photographed look directly at the lens and see the content of the tablet/mobile phone on the mirrored screen. The person being photographed has a good prompting effect without affecting the shooting.
- Compatible with various photographic equipment :


Equipped with a variety of 'adapter rings' and 'foam rings', which can be installed with SLRs, cameras, digital Cameras, DV machines and various mobile phones. There is also a dual-use 'mobile phone/tablet holder' that can be installed on both a mobile phone and a tablet.

### APP PLAYBACK SETTINGS


Scan the QR code on the back of the manual to download the APP.

Open the "GVM Teleprompter" software on your mobile phone → enter the APP, you can use. The APP sets the content, font size, playback speed, background color and whether to mirror the prompt.


APP main interface



Setting interface



Playback settings interface




- On the main interface of the APP, click " + " in the upper left corner to create a play file, you can choose "Add directly" is written on the APP, and can also import existing txt or Word files on the phone. The play file is created → a new play file appears on the main interface of the APP.

- On the main interface of the APP, click on the right side of the file to be set:
  - "Delete Files";
  - "Modify Files";
  - "To enter the play interface → click " on the play interface to start / pause the text; Click " ; " in the lower right corner to set the font size, playback speed, and background when playing text. Color and whether it is mirrored; click on the " in the lower left corner to return to the main interface of the APP.
- On the main interface of the APP, click " in the upper right corner to enter the setting interface → click on the play setting to enter the playback setting interface. Here you can also set the font size and broadcast, Play speed, background color and whether to mirror.

### REMOTE CONTROL APP

When using our APP to play text, you can use the Bluetooth controller we allocate to. The text playback is controlled by "start/pause". The controller connects to the APP via Bluetooth Take control. Turn on the phone's Bluetooth → find the Bluetooth named "AB Shutter3" and connect → wait Connection → After the connection is successful, press any one of the two buttons of the controller to control "Start / Pause" of APP text playback.



### PRECAUTIONS

- The product is not waterproof, please use it in rainproof environment.
- The product is not anti-corrosion, therefore do not let the product touch any corrosive liquid.
- When using the product, make sure the product is put firmly and prevent from falling and damage.

### USE AND PRESERVATION

Do not store the machine in a highly humid, direct sunlight environment.

**Cleaning:** Please use a damp cloth for cleaning. Do not use any detergent or soluble liquid, otherwise, it will damage the surface processing layer.

**Maintenance:** If the machine is faulty or the performance is degraded, please do not repair it by yourself, so as not to damage the machine and lose the right of warranty. In case of machine failure, please contact us in time, we will do our best to do our best for you.

**Accessories :** Please use the accessories provided by manufacturer and approved ones, in order to maximize the performance.

**Guarantee :** Do does not modify the product, or you will lose the right of maintenance.

### PACKING LIST

Name	Quantity	Notes
Teleprompter	1	
tablet clip/phone clip	2	
Adapter ring	8	
Foam ring	5	
Thumb screw 1/4 Screw	3	
Phone clip support	1	
Dust cover	1	
Bluetooth controller	1	