

封底和封面的另一面空白，书本形式

封底

封面

120.00 mm

160.00 mm

Web: www.gvmed.com
E&H Email: gh@gvmed.com
GVM Email: support@gvmed.com
Amazon Email: amazon-support01@gvmed.com
Warehouse Add: 4301 N Delaware ave, unit D, PHILADELPHIA, PA 19137, USA

GVM-Y30D160 / GVM-Y60D256

CONTENTS

Product introduction	Page 1
Disclaimers	Page 1
GVM-Y30D160 Product parameter	Page 2
GVM-Y60D256 Product parameter	Page 3
Product structure analysis	Page 4
Installation method	Page 5, 6
Description of product control keys	Page 7
Function introduction and instruction for use	Page 8, 9
APP connection and APP control	Page 10, 11
Precautions	Page 11, 12
Simple faults and troubleshooting	Page 13
Use and preservation	Page 13
Packing list	Page 14

PRODUCT INTRODUCTION

Welcome to "GVM-Y30D160 / GVM-Y60D256". This product is specially designed for senior photography enthusiasts. The product is suitable for live / outdoor / studio photography, and also for YouTube video shooting. The main features of the product are:

- Step-less adjustable dual color temperature feature, color range 3200K ~ 5600K, Using LED bulbs, which is helpful to restore and enrich the color of objects and provide you with natural and vivid shooting effect.
- APP intelligent control system, which can be controlled by your smart mobile devices.
- With digital screen display and stable system, which can support 360 ° rotation and effectively control the light Line. You can customize the control of fill light, so that you can easily shoot the desired results.

We firmly believe that the correct use of this product will definitely help your shooting work. Before using the product, we strongly recommend that you carefully read the following user guide.

DISCLAIMERS

- Before using this product, please read the instructions carefully and make sure the product correctly. If you don't obey the instructions and warnings, you maybe cause harm to yourself and the people around, or even damage the product and other things around.
- Once you use this product, you are deemed to have read the disclaimer and warning carefully, understand and acknowledge all the terms and contents of this statement, and promise to take full responsibility for the use of this product and possible consequences.

GVM-Y30D160 PRODUCT PARAMETER

- Brand : GVM
- Product Model : GVM-Y30D160
- Product Type : Photography Fill Light
- Product Name : Photography lights
- Function / Feature : APP, Joint control, LED digital display

High color rendering index light beads

- Color Rendering Index : ≥97
- Color Temperature : 3200K-5600K
- Brightness: 2300lux/0.5m ; 800lux/1m
- Light Adjustment Method : Stepless adjustment
- Lamp Beads Quantity : 160
- Product Weight : 2KG
- Power : 30W
- Product Size(mm) : 328*328*40
- Cooling : Natural heat dissipation
- Product Material : Aluminum alloy
- Voltage : DC15V
- Power Supply : DC15V/3A
- Power Supply Mode : DC input & Battery
- Battery Capacity : NF series battery * 2 (sold separately)
- Commodity Origin : Huizhou, China

- Color Rendering Index : ≥97
- Color Temperature : 3200K-5600K
- Brightness: 5100lux/0.5m ; 1750lux/1m
- Light Adjustment Method : Stepless adjustment
- Lamp Beads Quantity : 256
- Product Weight : 2.7KG
- Power : 60W
- Product Size(mm) : 430*418*40
- Cooling : Natural heat dissipation
- Product Material : Aluminum alloy
- Voltage : DC15V
- Power Supply : DC15V/4A
- Power Supply Mode : DC input & Battery
- Battery Capacity : NF series battery * 2 (sold separately)
- Commodity Origin : Huizhou, China

PRODUCT STRUCTURE ICON

INSTALLATION METHOD

- The lamp can be installed and fixed on the bracket by rotating the knob clockwise, and unloaded by rotating in the counterclockwise direction.

DESCRIPTION OF PRODUCT CONTROL KEYS

- DC15V power input interface
- Power switch
- Mode button/WIFI reset button: Modes include master mode and slave mode; WIFI username and password reset button
- Channel addition and subtraction key: adjust channel (0~11)
- Brightness indicator: when adjust the brightness knob, the indicator is on
- Color temperature indicator: when adjust the color temperature knob, the indicator is on
- Note: indicator ⑤ and indicator ⑥ will be on simultaneously when in slave mode
- Nixie tube: show value including lightness, color temperature and channel
- Color temperature adjustment button: adjust the color (3200K~5600K)
- Brightness adjustment button: adjust the brightness (10%~99%)

FUNCTION INSTRUCTION & INSTRUCTION FOR USE

- Mode selection:**
The mode is divided into master mode and slave mode. Tap the mode key to switch (default master mode for startup).

MODE Master: Adjust brightness, color temperature and channel through knobs and buttons, and can also connect APP. These parameters of lamp can be controlled through APP, and slave computers of the same channel can be controlled synchronously.

MODE Slave: Brightness and color temperature cannot be adjusted, only channel values can be set.

- Regulation channel : range 0~11**
Set channel value using channel addition and subtraction key.

- Adjust brightness (BRG): range 10%~99%**
In the master mode, brightness can be adjusted by rotating brightness level knob or APP.

- Adjust color temperature (CCT): range 3200K~5600K**
In the master mode, color temperature can be adjusted by rotating brightness level knob or APP.

- Indicator light**
• Master mode when the brightness is adjusted by brightness level knob or APP, the brightness indicator light is on, and the color temperature indicator light is off. When the color temperature is adjusted by the color temperature adjusting knob or APP, the color temperature indicator will be on, and the brightness indicator will be off.

APP CONNECTION AND APP CONTROL

Scan the QR code on the back of the manual to download the APP

Set master mode for the photography light (automatically as a master mode when switching on the machine), open "GVM Easily" APP on the mobile phone (meanwhile turn on WIFI on the phone), register the APP account (as long as the email format is correct, the email account password can be entered at will, because the next time you open the APP, you will automatically login), in the main menu in the APP—switch the devices—select "Single/Double color temperature light", then in the main menu in APP—set—select "switch WIFI", and connect photography light (WIFI initial username: GVM_LED, password: gvm_admin), once it shows "Device connection GVM_LED", return back to the main interface, after it shows "Connected" in the main interface, it is allowed to control the lightness, color temperature, channel value or switch on and off through the control key in APP, and also the slave machines.

APP CONNECTION AND APP CONTROL

Scan the QR code on the back of the manual to download the APP

Set master mode for the photography light (automatically as a master mode when switching on the machine), open "GVM Easily" APP on the mobile phone (meanwhile turn on WIFI on the phone), register the APP account (as long as the email format is correct, the email account password can be entered at will, because the next time you open the APP, you will automatically login), in the main menu in the APP—switch the devices—select "Single/Double color temperature light", then in the main menu in APP—set—select "switch WIFI", and connect photography light (WIFI initial username: GVM_LED, password: gvm_admin), once it shows "Device connection GVM_LED", return back to the main interface, after it shows "Connected" in the main interface, it is allowed to control the lightness, color temperature, channel value or switch on and off through the control key in APP, and also the slave machines.

PRECAUTIONS

- Please use the matching power adapter or lithium battery with the same specification to power the product. Do not use power adapter with different output voltage parameters.
- The product is not waterproof, please use it in rainproof environment.
- The product is not anti-corrosion, therefore do not let the product touch any corrosive liquid.
- When using the product, make sure the product is put firmly and prevent from falling and damage.
- If the product will not be used for a long time, please switch off the power to reduce energy loss.

USE AND PRESERVATION

Do not put the product in a highly humid, strong electromagnetic field, direct sunlight, high-temperature environment. If not use the product for a long time, disconnect the power and take out the battery.

Clean: Before clean, disconnect the power plug. And use wet cloth rather than any detergent or soluble liquid, avoiding damaging the surface layer.

Power: Make sure the power is in the demanded range, not too high or too low. Correctly load the battery, in order not the damage to machine.

Repairing: If there is fault or performance degradation, do not unpack the shell by yourself, avoiding damage the machine and lose the right of maintenance. When there is a fault, do not hesitate to contact us, and we will do our best to deal with the problem.

Accessories: Please use the accessories provided by manufacturer and approved ones, in order to maximize the performance.

Guarantee: Do does not modify the product, or you will lose the right of maintenance.

PACKING LIST

Name	Quantity	Notes
Main Machine	1	
Power Cord	1	
Adapter	1	
Carrying Case	1	
User Manual	1	